

Fig. 1




Fig. 2




Fig. 3

?

x

Page Setup

Advanced

Device Options

Mailbox Setup

Output Bin

Standard Output Tray

Stacker [up to Tray 5]

Sorter [up to Tray 5]

Tray 1

Tray 2

Tray 3

Tray 4

Tray 5

☐ Use Standard Tray when FULL

Tray type

☐ No Tray
☐ 5 Tray
☒ 10 Tray

Select Number of Mailboxes

5 Mail Boxes

Edit Mailbox

User Name...

User Setting

Save As

Delete

☒ Use Quick Setup monitor

OK

Cancel

Help

Fig. 4




Fig. 5




Fig. 6A




Fig. 6B




Fig. 7




Fig. 8




Fig. 9

?

x

Printer

OO-OOOO series

▼

Properties

Name:

Status: Ready

Type: OO-OOOO series

Where: LPT1:

Comment:

☐ Print to file

Print range

☒ All
 ☐ Pages from: 1 to:

Copies

Number of copies: 1

OK

Cancel

Fig. 10

111

112

113

114

Page Setup Advanced Device Options Mailbox Setup

Paper Size: Letter 8 1/2 x 11 in

Paper Source: Automatically Select

Copy Count: 1 [1- 999]

Orientation

☒ Portrait ☐ Landscape

OK Cancel Help

Fig. 11

112

111

114

113

Page Setup Advanced Device Options **Mailbox Setup**

Output Bin

Standard Output Tray
 Stacker [up to Tray 5]
 Sorter [up to Tray 5]
 Tray 1
 Tray 2
 Tray 3
 Tray 4
 Tray 5

☐ Use Standard Tray when FULL

Tray type

☐ No Tray
☐ 5 Tray
☒ 10 Tray

Select Number of Mailboxes

5 Mail Boxes

Edit Mailbox User Name. . .

User Setting

Save As Delete

OK Cancel Help

Fig. 12

